

# Instruction Manual

## LORUS

CAL. YK35, YK36 (R23 SERIES)


## LORUS

### ■ CHARACTERISTICS


- Time/Calendar display:** Hour, minute, second, date, day of the week and month are displayed.
- Stopwatch:** The stopwatch can measure up to 24 hours in 1/100-second increments for the first 30 minutes, and in 1-second increments thereafter. Lap time measurement is available.
- Alarm:** The alarm can be set to ring at a designated time.
- Electro Luminescent Backlight:** The built-in electro luminescent backlight illuminates the display for easy viewing in the darkness.

### ■ DISPLAY AND BUTTON OPERATION

Day of the week      Hour      Minute




#### Button operation from normal Time Display



\* There is no Button E for Cal. YK36.

### ■ HOW TO SET THE TIME/CALENDAR


The setting sequence is shown below.



- Press Button C three times to enter the Time Setting mode. The second digits start flashing. The "2" appears on the display to indicate that the watch is in the Time Setting mode.

\* For Cal. YK36, different indicators appear on display.

- Press Button A simultaneously with a time signal to reset the second digits to zero. The second digits instantly start counting.



- \* When the second digits are counting any number between "30" and "59" and Button A is pressed, the second digits are reset to zero and one minute is added.
- Press Button B to confirm the second setting and move on to the minute setting. The minute digits start flashing.
  - Press Button A to adjust the minute digits.
    - \* Keep Button A pressed to forward the digits rapidly.
  - Press Button B to confirm the minute setting and move on to the hour setting. The hour digits start flashing.
  - Press Button A to adjust the hour digits.
    - \* When setting the hour, make sure that am/pm is set correctly.
  - Press Button B to confirm the hour setting and move on to the date setting.
  - Repeat the same procedures for all other settings; press Button A to adjust digits and press Button B to confirm the setting and move on to the next setting.
  - After all the adjustments are completed, press Button C to return to the Time display.

### ■ HOW TO USE THE STOPWATCH

The stopwatch can measure up to 24 hours in 1/100-second increments for the first 30 minutes, and in 1-second increments thereafter.



#### Standard Measurement

- Press Button C to enter the Stopwatch mode.
- Press Button A to start timing.
- Press Button A to stop.
- Press Button B to reset the stopwatch to zero.
- To exit the Stopwatch mode and return to the Time display, press Button C.

#### Lap Time Measurement

- Press Button C to enter the Stopwatch mode.
- Press Button A to start timing.
- To view lap time, press Button B while the stopwatch is counting. Lap time is shown on the display while the stopwatch continues to count internally.
- Press Button B again to go back to the display of the measurement in progress.
- Press Button A to stop timing.
- Press Button B to reset the stopwatch to zero.
- To exit the Stopwatch mode and return to the Time display, press Button C.

\* Lap time readings can be repeated by pressing Button B.

## ■ HOW TO SET THE ALARM

1. Press Button C two times to enter the Alarm Setting mode.  
The hour digits start flashing.
2. Press Button A to set the hour digits.
3. Press Button B to confirm the hour setting and move on to the minute setting. The minute digits start flashing.
4. Press Button A to set the minute digits.
5. Press Button C to confirm the alarm settings and return to the Time display.



### Arm or disarm the alarm

- To arm the alarm, press Button A and B simultaneously.
- The alarm is armed or disarmed alternately.
- While the alarm is armed, the alarm indicator appears on the display.

*\* For Cal. YK36, different indicators appear on display.*

### How to stop the alarm while sounding

To stop the alarm manually while sounding, press either Button A or B.

## ■ ELECTRO LUMINESCENT BACKLIGHT

Press either Button D or E in any mode to turn the back light on. The electroluminescent back light illuminates the display for easy viewing in the darkness.



*\* There is no Button E for Cal. YK36.*

## ■ LUMIBRITE WATCH

- \* If your watch is a LORUS LUMIBRITE watch, it has following features.

LORUS LUMIBRITE watches absorb and store light energy from natural and artificial light sources and emit light in the dark. They are made of environmentally friendly material, and therefore, are harmless to human beings and the environment.

- With a full charge, LORUS LUMIBRITE watches glow in the dark hours longer than conventional luminous watches of this type. If exposed to a light of more than 500 lux (i.e., the brightness of a typical office) for approximately 10 minutes, or direct sunlight for 2 minutes, they will glow for hours.
- Since LORUS LUMIBRITE watches emit the light they store, the brightness will decrease gradually over time. The length of time they will glow may also differ slightly depending on such factors as the brightness of and distance from the light source used to charge the watch.

## ■ BATTERY CHANGE

The miniature lithium battery CR2032 for Cal. YK35 and CR1620 for Cal. YK36, which powers your watch, should last approximately 2 years. However, because it is inserted at the factory, the actual life of the battery once in your possession may be less than 2 years. Be sure to replace the battery to prevent any possible malfunction as soon as it runs down. To replace the battery, we recommend taking the watch to a local watch repair shop.

## ■ CARE OF YOUR LORUS WATCH

This watch contains precise electronic components. Never attempt to open the case or remove the back cover.

### • BATTERY

**CAUTION**

**Do not expose the old battery to fire or recharge it. Keep it at a place beyond the reach of children. If a child swallows it, consult a doctor immediately.**

### • WATER RESISTANT

- \* If your watch is 200 M/20 BAR, 100 M/10 BAR or 50 M/5 BAR water resistant, it is so indicated on the dial/case back.

Condition of use Indication on the dial/case back	Accidental contact with water, such as splashes and rain	Swimming and taking a shower	Skin diving	Scuba diving
<b>No Indication</b>	NO	NO	NO	NO
<b>WATER RESISTANT</b>	YES	NO	NO	NO
<b>WATER RESISTANT (50M/5 BAR)</b>	YES	YES	NO	NO
<b>WATER RESISTANT (100M/10 BAR) or above</b>	YES	YES	YES	NO

- Do not operate the buttons when the watch is wet.
- If the watch is exposed to salt water, rinse it in fresh water and wipe it thoroughly dry.
- Should you find any water or condensation inside the watch, immediately have it checked. Water can corrode electric parts inside the case.

### Caution:

Leather straps are not water resistant except so indicated, even if the watch head is water resistant.

### • ALLERGIC REACTION

Because the case and band touch the skin directly, it is important to clean them regularly. If not, shirt sleeves may be stained and those with delicate skin may develop a rash. Please wear the watch with some play to avoid any possible allergic reaction. If you develop a rash on your wrist, stop wearing and consult a physician.

### • MAGNETISM/STATIC ELECTRICITY

Your watch will not be affected by magnetism generated by household electric appliances but keep your watch away from a place where the watch is subject to strong electric field and static electricity.

### • SHOCKS AND VIBRATIONS

Your watch may be worn for normal sports activities. However, be careful not to drop it or hit it on hard surfaces and avoid any severe impacts.

### • TEMPERATURE

Your watch works with stable accuracy within a temperature range between 0°C and 50 °C. Do not expose the watch to a place exceeding this temperature range.

### • CLEANING

Use only a soft cloth and clean water for cleaning your watch. Never use chemicals, especially soap.

## ■ SERVICE

When your LORUS watch requires repair or servicing, please see the enclosed WARRANTY/GUARANTEE.

Printed in China